



1:81,000

GIS MAP OF 33 KV SOURCE LINE OF BRAHMANBARIA PBS



Offices of Brahmanbaria PBS		
SL No	Type of Office	Office Name
1	Headquarter	Brahmanbaria PBS HQ
2	Zonal Office	Akhaura Zonal Office
3		Kasba Sadar Zonal Office
4		Kasba Zonal Office
5		Nabinagar Zonal Office
6		Nasirnagar Zonal Office
7	Sub-Zonal Office	Auroail Sub Zonal Office
8		Bijoyanagar Sub Zonal Office
9		Shemogram Sub Zonal Office
10		Shibpur Sub Zonal Office
11		Sultanpur Sub Zonal Office
12	Complain Center	Aulabazar Complain Center
13		Bahadurpur Complain Center
14		Bitgor Complain Center
15		Carghach Complain Center
16		Chandidar Complain Center
17		Chatalpar Complain Center
18		Dharmandal Complain Center
19		Dulalpur Complain Center
20		Guniaok Complain Center
21		Islampur Complain Center
22		Jintapur Complain Center
23		Krishnanagar Complain Center
24		Kuti Complain Center
25		Lalpur Complain Center
26		Mogra Complain Center
27		Nayanpur Complain Center
28		Tantar Complain Center

LEGEND	
PBS Boundary	---
Upazila Boundary	---
Union Boundary	---
33 KV Line	---
477 MCM	---
636 MCM	---
132/33 KV Grid S/S	---
33/11 KV Sub-Station	---
Switching Station	---
Devices	---
PBS Headquarter	---
Zonal Office	---
Sub-Zonal Office	---
Complain Center	---



132/33 KV Grid Sub-Station of Brahmanbaria PBS		
Name of Grid of Sub-Station	Capacity (MVA)	
Ashuganj Grid	75/116	
Brahmanbaria Grid	240/360	
Kasba Grid	240/240	
Total	555/716	
33/11 KV Sub-Station of Brahmanbaria PBS		
Sub-Station Type	No's of Sub Station	Capacity (MVA)
Existing 33/11 KV S/S (PBS)	17 (Nos.)	268.00
Existing 33/11 KV S/S (Private)	0 (Nos.)	0.00
Total		268.00
33 KV Distribution Line of Brahmanbaria PBS		
Conductor Size	Unit	Milage (Km.)
477 MCM	KM	246.85
636 MCM	KM	38.93
Total	KM	285.77

