



Laxmipur
Grid
240 MVA

132/33 KV Grid Sub-Station of Bhola PBS		
Name of Grid of Sub-Station	Capacity (MVA)	
Borhanuddin 225MW CCPP Grid	240/280	
Bhola 34.5 MW Rental Power Plant	34.5	
33/11 KV Sub-Station of Bhola PBS		
Sub-Station Type	No's of Sub Station	Capacity (MVA)
Existing 33/11 KV S/S (PBS)	13 (Nos.)	160.00
Existing 33/11 KV S/S (Private)	00 (Nos.)	0.00
Total =		160.00
33 KV Distribution Line of Bhola PBS		
Conductor Size	Unit	Milage (Km.)
477 MCM	KM	254.25
636 MCM	KM	11.16
500 RM	KM	2.40
Total	KM	267.81

Offices of Bhola PBS		
SL No	Type of Office	Office Name
1	Headquarter	Bhola PBS HQ
2	Zonal Office	Char Fashion Zonal Office
3		Porangonj Zonal Office
4		Lalmohon Zonal Office
5	Sub-Zonal Office	South Aica Sub-zonal Office
6		Tojumuddin Zub-zonal Office
7		Borhanuddin Sub-zonal Office
8	Area Office	Daulatkhan Area Office
9		Char Montaz Complain Center
10		Char Kukri Mukri Complain Center
11	Complain Center	Char Biswas Complain Center
12		Soshivushon Complain Center
13		Char Mujib Nagar Complain Center
14		Char Borhan Complain Center
15		Dularhat Complain Center
16		Raichand Complain Center
17		Kunjerhat Complain Center
18		Char Mozammel Complain Center
19		Char Johir Complain Center
20		Kheyaghat Complain Center
21		Shantirhat Complain Center
22		Majhkazi Complain Center
23		Shreepur Complain Center
24		Gazaria Complain Center
25		Mangol Sikder Complain Center
26		Mojom Complain Center

LEGEND	
International Boundary	—
Zonal Boundary	---
PBS Boundary	---
Upazila Boundary	---
Union Boundary	---
33 KV Line	---
477 MCM	---
132/33 KV Grid S/S	---
33/11 KV Sub-Station	---
Switching Station	---
Devices	---
PBS Headquarter	---
Zonal Office	---
Sub-Zonal Office	---
Area Office	---
Complain Center	---

